



























































































Original		Rechange		Original		Rechange	
	Standby/On		Power		Navigation		Pre Ch
	Open/Close		Eject		Menu		Menu
	TV		TV/R		Setup		Options
	DV		Smart		Title		List
	AV		AV		Up		Up
	Scan		Media		Down		Down
	1		1		Select		Ok
	2		2		Right		Right
	3		3		Left		Left
	4		4		Rec/OTR		Rec
	5		5		Edit		Guide
	6		6		Timer		Shift + AV
	7		7		Play		Play
	8		8		Stop		Stop
	9		9		Pause/Step		Pause
	0		0		Mute		Mute
	ADD/Clear		Exit		CH+		Ch +





Original		Rechange		Original		Rechange	
	CH-		Ch -		Random		Yellow
	Vol+		Vol +		PS/IS		Format
	Vol-		Vol -		Goto		3D
	I<<		I<<				
	>>I		>>I				
	<<		<<				
	>>		>>				
	Audio		Dual				
	Subtitle		Subt				
	Angle		Red				
	Disc Oper		Blue				
	Return		Back				
	Repeat		Text				
	Zoom		Shift + Eject				
	Slow		Shift + Play				
	Display		Info				
	Prog		Sleep				

