

























| Original | | Rechange | |
|---|--------|---|---------------|
|  | Power |  | Power |
|  | Sleep |  | Sleep |
|  | Mute |  | Mute |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/-- |  | Shift + Guide |
|  | Recall |  | Back |
|  | Source |  | AV |
|  | P.STD |  | Smart |

| Original | | Rechange | |
|---|--------------|---|---------|
|  | S.STD |  | Media |
|  | Menu/ATV |  | Menu |
|  | Up |  | Up |
|  | Right |  | Right |
|  | Down |  | Down |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | PR- |  | Ch - |
|  | PR+ |  | Ch + |
|  | Freeze |  | Pause |
|  | Info/Display |  | Info |
|  | Menu/DVB |  | D. Menu |
|  | [.≡]/TTX |  | Text |
|  | I/II |  | Dual |
|  | [≡x]/Exit |  | Exit |





| | Original | Rechange | Original | Rechange |
|---|-------------|--|----------|----------|
|  | [≡◆]/EPG |  Guide | | |
|  | [≡+]/FAV |  Pre Ch | | |
|  | [≡i]/TV.R |  TV/R | | |
|  | [≡?]/Subt |  Subt | | |
|  | [≡o]/Aspect |  Format | | |
|  | [≡..] |  List | | |
|  | Red |  Red | | |
|  | Green |  Green | | |
|  | Yellow |  Yellow | | |
|  | Blue |  Blue | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

