

























































	Original	Recharge		Original	Recharge
	Power		Power		Rec
	Home		Smart		Rec
	1		1		Stop
	2		2		Pause
	3		3		Play
	4		4		Vol+
	5		5		Vol-
	6		6		Setup
	7		7		Options
	8		8		I<< Prev
	9		9		>>I Next
	0		0		<< FR
	Goto		List		>> FF
	Mute		Mute		Up
	Display		Info		Left
	Audio		Dual		Enter
	Subtitle		Subt		Right
					Down
					Browser
					Media



