







































































| Original  |           | Rechange  |             | Original  |        | Rechange  |                             |
|---|-----------|---|-------------|---|--------|---|-----------------------------|
|    | Power     |    | Power       |    | --     |    | Guide / EPG / -/--          |
|    | Up / P+   |    | Up          |    | 0      |    | 0                           |
|    | Up / P+   |    | CH+ / Page+ |    | P < P  |    | Fav / Marker / PC           |
|    | Menu      |    | Menu / Home |    | PP     |    | Back / Return               |
|    | Left      |    | Left        |    | Vol+   |    | Vol+                        |
|    | Right     |    | Right       |    | I-II   |    | Audio / Lang I/II           |
|    | Down / P- |    | Down        |    | Mute   |    | Mute / Dimmer               |
|    | Down / P- |    | CH- / Page- |    | Vol-   |    | Vol-                        |
|    | 1         |    | 1           |    | Info   |    | Info / Angle                |
|   | 2         |   | 2           |   | Red    |   | Red / Netflix / Search      |
|  | 3         |  | 3           |  | Green  |  | Green / APP / Repeat        |
|  | 4         |  | 4           |  | Yellow |  | Yellow / YouTube / Repeat   |
|  | 5         |  | 5           |  | Blue   |  | Blue / Prime Video / Random |
|  | 6         |  | 6           |  | [TV]   |  | Shift + 1                   |
|  | 7         |  | 7           |  | [TV]   |  | TV/Radio /                  |
|  | 8         |  | 8           |  | [AV]   |  | AV / Input / RDS            |
|  | 9         |  | 9           |  | [ ≡ ]  |  | Text / Goto                 |





**Original**

**Rechange**

|  |       |  |                       |
|--|-------|--|-----------------------|
|  | [≡⊕]  |  | Subtitle / EQ         |
|  | [ /≡] |  | Picture / Format      |
|  | [≡X]  |  | Exit / Cancel / Clear |
|  | [≡⇅]  |  | Zoom / Size           |
|  | [≡?]  |  | Display / Media       |
|  | [≡i]  |  | Smart / List          |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |
|  |       |  |                       |





































































**Original**

**Rechange**

|  |  |  |  |
|--|--|--|--|
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |
|  |  |  |  |













| Original  | Rechange  | Original   | Rechange  |
|---|---|--|---|
|  Power     |  Power       |  9        |  9                             |
|  Up / P+   |  Up          |  +10      |  Guide / EPG / -/-             |
|  Up / P+   |  CH+ / Page+ |  0        |  0                             |
|  Menu      |  Menu / Home |  Repeat   |  Green / APP / Repeat          |
|  Left      |  Left        |  Search   |  Red / Netflix / Search        |
|  Select    |  OK          |  A→B      |  Yellow / YouTube / Repeat     |
|  Right     |  Right       |  Display  |  Display / Media               |
|  Down / P- |  CH- / Page- |  Audio    |  Audio / Lang I/II             |
|  Down / P- |  Down        |  Subtitle |  Subtitle / EQ                 |
|  1        |  1          |  Zoom    |  Zoom / Size                  |
|  2       |  2         |  Prog   |  TV/Radio /                  |
|  3       |  3         |  C      |  Blue / Prime Video / Random |
|  4       |  4         |  Angle  |  Info / Angle                |
|  5       |  5         |  Return |  Back / Return               |
|  6       |  6         |  Time   |  Sleep / Timer               |
|  7       |  7         |  <<     |  << / Tune-                  |
|  8       |  8         |  >>     |  >> / Tune+                  |







































| Original  | Recharge  | Original | Recharge |
|---|---|----------|----------|
|  |  I<< / Preset-         |          |          |
|  |  >>I / Preset+         |          |          |
|  |  Play / Slow           |          |          |
|  |  Pause / Step / Freeze |          |          |
|  |  Stop / Hold           |          |          |
|  |  Sound / Title         |          |          |
|  |  Eject / Surround      |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |
|   |   |          |          |





| Original    | Recharge  |                    |
|-------------|---|--------------------|
| On/Off      |    | Power              |
| Mute        |    | Mute / Dimmer      |
| Txt Stop    |    | Stop / Hold        |
| Tone+       |    | >> / Tune+         |
| Lang        |    | Sound / Title      |
| Menu audio  |    | Audio / Lang / III |
| Subt.List   |    | Subtitle / EQ      |
| Txt Expand  |    | Zoom / Size        |
| Sleep Timer |    | Sleep / Timer      |
| Return TV   |    | TV/Radio /         |
| Menu video  |    | D.Menu / Top       |
| Text        |   | Text / Goto        |
| Menu        |  | Menu / Home        |
| Menu Up     |  | Up                 |
| Info        |  | Info / Angle       |
| Menu Left   |  | Left               |
| OK Enter    |  | OK                 |

| Original   | Recharge  |                 |
|------------|---|-----------------|
| Menu Right |    | Right           |
| Menu Down  |    | Down            |
| Back       |    | Back / Return   |
| Volume+    |    | Vol+            |
| Chan.Up    |    | CH+ / Page+     |
| Volume-    |    | Vol-            |
| Display    |    | Display / Media |
| Chan.Down  |    | CH- / Page-     |
| 1          |    | 1               |
| 2          |    | 2               |
| 3          |    | 3               |
| 4          |   | 4               |
| 5          |  | 5               |
| 6          |  | 6               |
| 7          |  | 7               |
| 8          |  | 8               |
| 9          |  | 9               |



