











































































Original	Recharge	Original	Recharge
	Power		Power
	Source		AV
	Mute		Mute
	V-Format		Format
	Text		Text
	Menu		Menu
	Guide		Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK / List		Ok
	Exit		Exit
	Opt+		Options
	Back		Back
	P +		Ch +
	P -		Ch -
	i		Info
	Vol +		Vol +
	Vol -		Vol -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0





	Original	Recharge		Original	Recharge
	Subtitle	 Subt			
	Audio	 Dual			

