Mandis shop

Samsung AH59-02692P

Original		Rechange		Original	Rechange
	Power		Power		
SOURCE	Source	TIMER AV	AV		
	Vol +	VOL +	Vol +		
	Vol -	VOL −	Vol -		
	Mute	MUTE	Mute		
	Back	RETURN BACK	Back		
	I <<		I <<		
	>>I		>>I		
	Play	PLAY MODE ▶	Play		
	Pause		Pause		
SOUND EFFECT	Sound Effect	SETTINGS OPT	Options		
SOUND	Sound	SOUND DUAL	Dual		
SOUND CONTROL	Sound Control	AD SUBT	Subt		
Bluetooth POWER	Bluetooth	HOME SMART	Smart		
WOOFER	Woofer	APP MEDIA	Media		
AUTO POWER	Auto Power	SEARCH TV/R	TV/R		