Original		Rechange	
	Power		Power
	Mute	MUTE	Mute
F1	Red/F1	A	Red
F2	Green/F2	B	Green
F3	Yellow/F3	C	Yellow
IPTV	Blue/IPTV	D	Blue
	<<		<<
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	>>		>>
V.FORMAT	V.Format	PICTURE FORMAT	Format
RESOLUTION	Resolution	ECO 3D	3D
SUBTITLE	Subtitle	AD SUBT	Subt
	Rec	REC MODE	Rec
OPTION	Option	SETTINGS OPT	Options
AUDIO	Audio	SOUND DUAL	Dual

Original		Rechange	
TEXT	Text	REPEAT TEXT	Text
SAT	SAT	HOME SMART	Smart
INFO	Info	DISPLAY INFO	Info
RECAL	Recall	RETURN BACK	Back
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
+ VOL	Vol+	+ VOL	Vol +
VOL −	Vol-	VOL −	Vol -
FAV	FAV	FAV PRE-CH	Pre Ch
EPG	EPG	-/-- GUIDE	Guide
+ PAGE	Page+	+ CH	Ch +
PAGE −	Page-	CH −	Ch -

Original		Rechange		Original	Rechange
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
SLEEP	Sleep	PROG SLEEP	Sleep		
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R		