Mandis shop

LG COV33552401

Original	Rechange
Power	Power
Open/Close	Eject / Surround
Vol +	Vol +
F	Setup / OPT /
Preset/Folder Up	CH+ / Page+
Vol -	Vol -
Mute	Mute / Dimmer
Preset/Folder	CH- / Page-
Program/Memor	Smart / List
Display Mode	Display / Media
Delete	Exit / Cancel / Clear
Sound Effect	Audio / Lang I/II
Repeat	Green / APP / Repeat
Info	Info / Angle
I<<</Tuning-	I<< / Preset-
Play	Play / Slow
Pause	Pause / Step / Freeze

Original	Rechange
Tuning+/>>I	>>I / Preset+
Dimmer	Shift + Mute / Dimmer
Stop	Stop / Hold
Sleep	Sleep / Timer
Clock	Shift + Sleep / Timer
Alarm	OK
USB Rec	Rec / Rec Mode
RDS/Set	Menu / Home
PTY	Zoom / Size
*	Down

https://tout-telecommande.fr/fr/LG/10721-5284-telecommande-de-remplacement-pour-LG-COV33520.html