Mandis shop

Pioneer CU-MJ004

Original	Rechange
Power	Power
Function	Menu / Home
Volume-	Vol -
Volume+	Vol +
Surr & ST Wide	Audio / Lang I/II
Flat	Sound / Title
FM Mono	Red / Netflix / Search
Effect On/Off	Eject / Surround
GEQ On/Off	Subtitle / EQ
Station Down	CH- / Page-
Station Up	CH+ / Page+
Random CD	Blue / Prime Video / Random
PGM CD	TV/Radio /
I<< CD	I<< / Preset-
>>I CD	>>I / Preset+
Disc CD	Yellow / YouTube / Repeat
Stop CD	Stop / Hold

Original	Rechange
Pause CD	Pause / Step / Freeze
Play CD	Play / Slow
< Deck I	Left
Deck I >	Right
< Deck II	Shift + Left
Deck II >	Shift + Right
<< Deck I	Down
>> Deck I	Up
<< Deck II	Shift + Down
>> Deck II	Shift + Up
Stop Deck I	OK
Rec Deck II	Shift + Rec / Rec Mode
Pause Deck II	Shift + Pause / Step /
Stop Deck II	Shift + OK
Wake Up	Back / Return
Sleep	Sleep / Timer
Snooze	Info / Angle

https://tout-telecommande.fr/fr/Pioneer/1613-204-telecommande-remplacement-pour-Pioneer-CU-MJ004.html