Mandis shop

Philips 996580001719HIFI

Original		Rechange	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
AUDIO-IN	Audio-In	LANG I/II AUDIO	Audio / Lang I/II
COAX	Coax	FORMAT PICTURE	Picture / Format
OPTICAL	Optical	OPT-TOOLS SETUP	Setup / OPT /
V.SURR	V.Surr	GOTO TEXT	Text / Goto
AUDIO SYNC +	Audio Sync +		Up
BASS -	Bass -		Left
BASS +	Bass +		Right
AUDIO SYNC -	Audio Sync -		Down
	Vol +	+ VOL	Vol+
HDMI ARC	HDMI/ARC	LIST SMART	Smart / List
TREBLE +	Treble +	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol-
TREBLE -	Treble -	CH PAGE −	CH- / Page-
HDMI 1	HDMI 1	TV 1	1
HDMI 2	HDMI 2	DVD 2	2

Original		Rechange	
AUX	Aux	AUX - HDD 7	7
Bluetooth	Bluetooth	BLUETOOTH 9	9
ON	Auto Volume On	SHIFT + + VOL	Shift + Vol+
ON NIGHT MODE	Night Mode On	SHIFT + + CH PAGE	Shift + CH+ /
OFF	Auto Volume	SHIFT + VOL −	Shift + Vol-
NIGHT MODE OFF	Night Mode Off	SHIFT + CH PAGE −	Shift + CH- /

https://tout-telecommandes.fr/fr/Philips/1058072-66017-telecommande-de-remplacement-pour-Philips-Fidelio-996580001719.html