Mandis shop

Sharp RRMCG0106AWSA

Original	Rechange	Original	Rechange
On/Standby	Power	Band	TV/Radio /
Stop	Stop / Hold	X-Bass/Equalizer	Audio / Lang I/II
Play	Play / Slow	Vol-	Vol-
Pause	Pause / Step / Freeze	Vol+	Vol+
Back/Random	Back / Return		
I<</<</Preset	I<< / Preset-		
Preset Up/>>/>>I	>>I / Preset+		
Memory/Set	Menu / Home		
Tuning-	<< / Tune-		
Tuning+	>> / Tune+		
Clear	Exit / Cancel / Clear		
Timer Set	D.Menu / Top		
Timer	Shift + Sleep / Timer		
Sleep	Sleep / Timer		
Timer Down	Down		
Timer Up	Up		
Function	Setup / OPT / Tools		

https://tout-telecommandes.fr/fr/Sharp/1066113-2457-telecommande-de-remplacement-pour-Sharp-RRMCG0106AWSA.html