Mandis shop

# Yamaha FSR80

| Original | Rechange |
|---|---|
| Power | Power |
| TV | 1 |
| BD/DVD | 2 |
| Analog | 3 |
| Portable | 4 |
| Bluetooth | 9 |
| Bluetooth | Fav / Marker / PC |
| Clear Voice | Exit / Cancel / Clear |
| Univolume | Smart / List |
| Audio Delay | Audio / Lang I/II |
| Movie | Red / Netflix / Search |
| Music | Green / APP / Repeat |
| Sports | Yellow / YouTube / Repeat |
| Game | Blue / Prime Video / Random |
| Tv Program | Guide / EPG / -/-- |
| Stereo | Sound / Title |
| YSP Position L | Left |

| Original | Rechange |
|---|---|
| YSP Position C | OK |
| YSP Position R | Right |
| Subwoofer+ | CH+ / Page+ |
| Volume+ | Vol+ |
| Subwoofer- | CH- / Page- |
| Mute | Mute / Dimmer |
| Volume- | Vol- |
| CH Level | AV / Input / RDS |
| Tv Remote Control Learn | TV/Radio / |
| Tv Remote Control Repeater | Zoom / Size |

https://tout-telecommandes.fr/fr/Yamaha/1067302-66004-telecommande-de-remplacement-pour-Yamaha-FSR80-ZG807600.html